



NOTES: POURED-IN-PLACE CONCRETE OR CONCRETE BLOCK (CMU) MAY BE SUBSTITUTED FOR TREATED WOOD BLOCKING.

REFERENCE GUIDELINE DETAIL R-12 FOR ALTERNATE CORNER TRANSITION DETAILS, TIE-IN WITH MM 6125-FR (FABRIC REINFORCED) MEMBRANE AND FLASHING WITH FLEX-FLASH MB.



Monolithic
Membrane
6125-FR
ROOFING SYSTEMS

AMERICAN HYDROTECH, INC.

TYPICAL PARAPET
AT PRECAST WALL

3"=1'-0"

R-11E